

PH / Temperature meter PH55

Mechanisms: Withdraw protection; Turn on the PH55 pressing the ON / OFF Button; Dip the electrode into the liquid to measure. The PH55 automatically compensates for temperature. To turn off the meter, press the button ON / OFF / CAL.

Calibration: Press the ON / OFF / CAL button until the message OFF is replaced by the CAL message. The meter is on calibration mode, and with the message "pH7.01 use", asks to be immersion in calibration liquid pH7.01. The meter will indicate "OK" and it will ask to be immersed in pH4.01 liquid. Then of being immersed in pH4.01 liquid, after a few seconds, will indicate "OK2" with which it is calibrated in 2 points. For a single-point calibration, dip the tip of the meter in a calibration liquid (PH4, PH7 or PH10); Press the ON / OFF / CAL button until you go into calibration; The meter will recognize the liquid and will be calibrated when the OK. To exit calibration mode, press the Set / Hold button.

Electrode change: Unscrew the white ring, Remove the electrode and replace it with a new one, being careful not to damage the connections.

IMPORTANT: Never use distilled or deionized water as storage liquid.